

### LEAK CURRENT HITESTER ST5540, ST5541



# Leak Current Measurement - Essential to Electrical Safety

- Uninterrupted polarity switching function dramatically reduces cycle time
- Support for rated currents up to 20 A gives the instrument more than adequate capability for testing products designed to comply with new standards

For medical-use electrical devices and essential to electrical safety

# Compliance with IEC 60601-1:2005 Ed 3.0, JIS T 0601-1:2012

(\*Starting on June 1, 2012, medical electrical equipment sold in the EU must comply). Model ST5540 comply with IEC 60601-1:2005 +A1:2012 (Ed 3.1), and IEC 62353 of 2017

# Compliance with Electrical Appliances and Materials Safety Act,

JIS, IEC, and UL standards for general-use electrical devices





## **For Medical Electrical Devices**


# ST5540

# **Complies with all standards (suitable for use with all networks)**

Leak current parameters as defined for medical-use electrical devices include ground leak current, contact current, patient leak current, and patient measurement current. The ST5540 provides a single solution for measuring all of these leak current variants.

## Complies with IEC 60601-1:2005 +A1:2012 (Ed 3.1)

In order to prevent the danger of electric shock, electrical devices use power supplies that are isolated from parts of the device that may come into contact with the body. However, it is impossible to achieve infinite insulation resistance. Some leak current always exists, and its magnitude changes as the insulation degrades over time. The LEAK CURRENT HITESTER ST5540/ST5541 provides an easy-to-operate solution for measuring leak current in electrical devices, making it eminently suitable for use in an extensive array of applications, ranging from production lines to equipment maintenance and inspections.




#### ■ Comparison of ST5540 Functionality

#### Measurement mode Category Standard compliance • IEC60601-1 (Ed 3.1) Patient leak current (between parts of device that come into contact with · Medical industry (Japan Association for patient and ground) • IEC60990 Clinical Engineering Technologists, etc.) • Medical device manufacturers and dealers • IEC62353 Patient leak current (external SIP/SOP voltage) · Medical device repair and maintenance Patient leak current (external voltage at specific F-type applied part) Patient leak current (current resulting from external voltage at parts of ST5540 · Hospitals device that come into contact with patients) Patient measurement current Medical-use Total patient leak current (between parts of device that come into contact electrical devices Total patient leak current (external SIP/SOP voltage) Total patient leak current (external voltage at specific F-type applied part) Total patient leak current (current resulting from external voltage at parts of device that come into contact with patient) · Electrical vehicle standards UL. Contact current (between device enclosure and lines) · Public agencies 2231-1 and UL 2231-2 · Electric vehicle manufacturers Contact current (between device enclosure and ground) General-use • Manufacturers of general electrical devices • Electrical Appliances and Contact current (between device enclosure and device enclosure) electrical devices Ground leak current · Household appliance industry Materials Safety Act · IEC, JIS, and UL standards · Information device industry Free current measurement \*The ST5540 also complies with old standards.

# For Standard- and Regulation-compliance ST5541

# **Measurement of General-use Electrical Devices**

ST5541 provides standard support for standard-compliant networks (excluding medical-use electrical devices).



There are various standards in place concerning networks (body simulated resistance), and a standard-compliant network is required in order to make measurements.

#### ■ Comparison of ST5541 Functionality

#### Measurement mode Standard compliance Category Contact current (between device enclosure and lines) · Public agencies · Electrical vehicle standards UL ST5541 · Electric vehicle manufacturers 2231-1 and UL 2231-2 Contact current (between device enclosure and ground) General-use Contact current (between device enclosure and device enclosure) Manufacturers of general electrical devices · Electrical Appliances and Materials electrical devices · Household appliance industry Ground leak current Safety Act Free current measurement · Information device industry · IEC, JIS, and UL standards




## ST5540/ST5541 Features

#### Uninterrupted polarity switching function

The ability to conduct tests without turning off the power when switching the power supply polarity dramatically reduces cycle times.

The ST5540/ST5541 can switch polarity without stopping the supply of power to the device under measurement. Old models require that the device under measurement be turned off and then back on again when switching polarity, but the ST5540 and ST5541 let you progress smoothly to the next testing process.



\*Only the ground is switched, allowing an uninterrupted supply of power.

#### Circuit breaker for device under measurement

The instrument's workbench-type design features a terminal block and a circuit breaker on the front panel, making it deal for embedding in test lines and simplifying connectivity with the device being measured, even while rack-mounted.



#### Improved test reliability

Blown fuse check function

When measurement starts, the instrument checks for unintentional probe misalignment using of a preconfigured lower limit setting.

#### Safety conductor current measurement function

The ST5540/ST5541 can perform safety conductor current measurement as defined in standards such as IEC 60990 and IEC 60950-1.

#### Automatic measurement functionality

Simple operation allows you to switch power supply polarity and automatically make measurements with the target device in the normal and single-fault states, displaying the peak values. You can also set the measurement time and wait time. These capabilities help reduce operation time.

#### 110% voltage application jack

The instrument's 110% voltage application jack, which is used during testing of medical devices, outputs the target device line power supply voltage as-is. The polarity can be switched (ST5540 only).

#### Save measurement data for 100 devices

Measurement data (peak values) can be stored in the instrument's built-in memory. Saved data can be checked on the stored data reference screen after measurement is complete. Data can be stored for up to 100 test targets, with each target being identified by a registered device name and control number. Additionally, the instrument can store a maximum of 2,000 peak value data points. Together, these capabilities eliminate the need to jot down measured values at the measurement site.

#### Simple, interactive operation

The ST5540/ST5541 uses a touch panel that lets you configure settings by touching selections in response to information displayed on the panel, keeping operation simple.

#### Peak value display.

Displays the type of power supply fault and the peak value for the leak current, which varies with target device operation.

Power supply polarity/device status/measurement current

#### Allowable value

The maximum allowable value under the standard in question is automatically set. Settings can also be changed as desired by the user.

#### Ability to store up to 30 sets of measurement conditions

The instrument can save and load up to 30 sets of measurement conditions, allowing you to immediately switch between conditions.



[Measurement screen]

Current measured value

Judgment result based on set allowable value

#### Data storage

Measurement data: For up to 100 target devices Measurement conditions: Up to 30 sets

## **Expandability for the Future**

#### All the switch terminals needed for standard-compliant measurement

The ST5540/ST5541 provides the terminals needed to perform leak current measurement in compliance with IEC 60601-1 and JIS T0601-1, eliminating the need for the user to provide external switches.

#### Connection terminals

S10 terminal : Switch for connecting a function ground terminal to the measurement power supply system's ground point

Allows connectivity to ground to be configured during leak current measurement.

S12 terminal : Switch for connecting the parts of device that come into contact with the patient to

the measurement power supply circuit's ground point
Allows connectivity to ground to be configured during leak current measurement.


S13 terminal : Switch for connecting contactable metallic parts that are not protectively grounded to

Allows connectivity to ground to be configured during leak current measurement.

E terminal : Connected to the E (earth) LINE IN terminal.

This terminal is always connected and cannot be configured.

\*S10, S12, S13, and E are available on the ST5540 only.




#### Standard USB interface

The ST5540/ST5541's standard USB interface simplifies automatic testing on manufacturing lines and in similar installations.

1 : Connectivity not supported for USB memory. Data communications only.
 Connect be used while on PS 222C connection is active.

#### ■ Standard RS-232C port

The ST5540/ST5541's standard RS-232C port can be used to control the instrument from a computer (option).



# Separation of the instrument's power supply and target device lines

The instrument's power supply and target device line power supply are separated, helping prevent damage due to the inadvertent input of an incorrect supply voltage. There's no need to change the ST5540/ST5541's supply voltage, even if the target device's supply voltages changes.

#### Support for rated currents of up to 20 A

The ST5540/ST5541 supports currents of up to 20 A and voltages of up to 250 V. Its ability to accommodate large currents allows it to be used with a more extensive range of target products, including devices from new fields such as electric vehicles and household appliances.

( Line power supply terminal block for device under test )

#### ■External control via EXT I/O

Start of measurement and loading of measurement conditions can be controlled from an external source. Additionally, judgment results, test signals, and other data can be output, making it possible to use the instrument to develop an automated line.

Input signals	Active-low input
Max. pplied voltage	EXT.DCV terminal input voltage
High level	EXT.DCV terminal input voltage or open
Low level	0.3 VDC or less
Output signal	Open collector output
Max. load voltage	24 VDC (when not using the EXT.DCV terminal)
Max. output current	60 mA DC per signal (low level)

In addition to outputting judgment results for each measurement item, the instrument also provides T-FAIL output, which is generated continuously once a FAIL result is encountered during automatic testing.

#### EXT I/O description

#### ●Output TEST

: Outputs low continuously during automatic measurement.

MEAS : Outputs the measurement count automatic measurement and measurement of multiple items.

PASS : Outputs the PASS judgment result for each measurement item.

FAIL : Outputs the FAIL judgment result for each measurement item.

LOW: Generates continuous output once a low signal is encountered during automatic testing.

T-FAIL : Generates continuous output once a FAIL result is encountered during automatic testing.

INT.DCV : Generates internal 5 VDC output (not isolated from internal circuitry).

INT.GND : Generates internal GND output (same as the case ground level).

Input

START : Starts automatic measurement at low.

STOP : Forcibly terminates measurement at low.

LOAD (0 to 4) : Loads saved panels (30 panels).

EXT.DCV : Accepts external power supply input from 5 VDC to 24 VDC.

EXT.COM : Accepts external COM input.

KEYLOCK : Disables switches other than the start switch

#### ST5540/ST5541 Specifications (Accuracy guaranteed for 1 year)

#### ■ General specifications

Display	$320 \times 240$ dot matrix LCD (with backlight)
Control	6 × 6 matrix touch panel
Operating temperature and humidity range	0°C to 40°C, 80% RH or less (non-condensing)
Storage temperature and humidity range	-10°C to 50°C, 80% RH or less (non-condensing)
Temperature and humidity range within which accuracy is guaranteed	23°C ±5°C, 80% RH or less (non-condensing)
Guaranteed accuracy period	1 year
Operating location	Indoor use at an elevation not exceeding 2,000 m
Instrument power supply	100/120/220/240 VAC, as specified by customer Rated power supply frequency: 50/60 Hz Rated power: 30 VA
Line power supply for device being measured and outlet	Rated supply voltage: 100 to 250 VAC Rated power supply frequency: 50/60 Hz Rated current: Input, terminal block: 20 A Output, terminal block: 20 A

Outlet max. allowable	50 mA
leak current	
Dielectric strength	Between power supply terminals and protective ground: 1.39 kV AC (5 mA), 15 sec
	Between measurement terminals and power supply terminals: 2.30 kV AC (10 mA), 15 sec
	Between measurement terminals and control circuit: 2.30 kV AC (10 mA), 15 sec
Standard compliance	EMC: EN 61326
	Safety: EN 61010
Conductive RF	3% f.s. or less at 3 V
Magnetic field effects	(Representative value when conducting measurements in
	the AC 500 μA range)
Accessories	ST5540: One set of L2200 test leads (one red, one black) + one
	red L2200 test lead
	ST5541: One set of L2200 test leads (one red, one black)
	Enclosure Probe 9195 × 1 , CD-ROM × 1 (USB Driver)
	power cord × 3 (1 for instrument and 2 for measuring instrument line supply use)
	spare fuse × 1 (250 V F 50 mA L, measurement use)
Dimensions	Approx. 320 (W) × 110 (H) × 253 (D) mm
Mass	Approx. 4.5 kg

#### Leak current measurement unit

Allowable measurement current Max. 50 mA (DC / AC+DC mode) Max. 75 mA (AC peak mode)  Measurement ranges  DC / AC / AC+DC mode: $50  \mu A/500  \mu A/5  mA/50  mA$ AC peak mode: $500  \mu A/1  mA/10  mA/75  mA$ AUTO/HOLD  Trigger method  Measurement terminals  T1 terminal, T2 terminal (with built-in fuse holder), T3 terminal ( $110\%$ voltage application terminal: ST5540 only) (*Step-up isolation transformer required for $110\%$ application.)  Measurement methods  Measurement methods True rms measurement Measurement Measurement of voltage drop across body simulated resistance points Calculation and display of current values  True rms measurement Measurement unit floats relative to instrument ground.  A/D conversion method $\Delta\Sigma$ method ( $20$ -bit)  linstrument-to-ground capacitance  Input resistance $1  M\Omega \pm 1\%$ (single-end input)  Not including voltage measurement unit, body simulated resistance (current detection circuit)				
Max. 75 mA (AC peak mode)           Measurement ranges         DC / AC / AC+DC mode:50 μA/500 μA/5 mA/50 mA           AC peak mode:500 μA/1 mA/10 mA/75 mA           Range switching         AUTO/HOLD           Trigger method         Manual: Generates trigger automatically internally, free-run measurement. Automatic: Starts measurement based on external start signal.           Measurement terminals         T1 terminal, T2 terminal (with built-in fuse holder), T3 terminal (110% voltage application terminal: ST5540 only) (*Step-up isolation transformer required for 110% application.)           Measurement methods         Measurement of voltage drop across body simulated resistance points Calculation and display of current values True rms measurement unit floats relative to instrument ground.           A/D conversion method         ΔΣ method (20-bit)           Instrument-to-ground capacitance         200 pF or less (between T1/T2 terminal and case ground)           Input resistance         1 MΩ ±1% (single-end input)           Not including voltage measurement unit, body simulated resistance (current detection circuit)           Input capacitance         150 pF or less (between T1 and T2 terminals)	Measurement current	DC / AC / AC+DC / AC peak		
Measurement ranges         DC / AC / AC+DC mode:50 μA/50 μA/50 μA/5 mA/50 mA           Range switching         AUTO/HOLD           Trigger method         Manual: Generates trigger automatically internally, free-run measurement. Automatic: Starts measurement based on external start signal.           Measurement terminals         T1 terminal, T2 terminal (with built-in fuse holder), T3 terminal (110% voltage application terminal: ST5540 only) (*Step-up isolation transformer required for 110% application.)           Measurement methods         Measurement of voltage drop across body simulated resistance points Calculation and display of current values True rms measurement Measurement unit floats relative to instrument ground.           A/D conversion method $\Delta\Sigma$ method (20-bit)           Instrument-to-ground capacitance $\Delta\Omega$ method (20-bit)           Input resistance $1$ MΩ ±1% (single-end input)           Not including voltage measurement unit, body simulated resistance (current detection circuit)           Input capacitance         150 pF or less (between T1 and T2 terminals)	Allowable measurement current	Max. 50 mA (DC / AC / AC+DC mode)		
AC peak mode: $500  \mu A/1  mA/10  mA/75  mA$ AUTO/HOLD  Trigger method  Manual: Generates trigger automatically internally, free-run measurement. Automatic: Starts measurement based on external start signal.  Tl terminal, T2 terminal (with built-in fuse holder), T3 terminal ( $110\%$ voltage application terminal: ST5540 only) (*Step-up isolation transformer required for $110\%$ application.)  Measurement methods  Measurement of voltage drop across body simulated resistance points Calculation and display of current values True rms measurement Measurement unit floats relative to instrument ground.  A/D conversion method  A\( \D \text{ conversion method} \)  Input resistance  1 M\( \D \text{ 2} 1\% (\text{ single-end input)} \)  Not including voltage measurement unit, body simulated resistance (current detection circuit)  Input capacitance  150 pF or less (between T1 and T2 terminals)		Max. 75 mA (AC peak mode)		
Range switching  AUTO/HOLD  Trigger method  Manual: Generates trigger automatically internally, free-run measurement. Automatic: Starts measurement based on external start signal.  Measurement terminals  T1 terminal, T2 terminal (with built-in fuse holder), T3 terminal (110% voltage application terminal: ST5540 only) (*Step-up isolation transformer required for 110% application.)  Measurement methods  Measurement of voltage drop across body simulated resistance points Calculation and display of current values  True rms measurement methods of current values  True rms measurement unit floats relative to instrument ground.  A/D conversion method $\Delta\Sigma$ method (20-bit)  Input resistance $1 M\Omega \pm 1\%$ (single-end input)  Not including voltage measurement unit, body simulated resistance (current detection circuit)  Input capacitance $150  \text{pF}$ or less (between T1 and T2 terminals)	Measurement ranges	DC / AC / AC+DC mode:50 µA/500 µA/5 mA/50 mA		
Trigger method  Manual: Generates trigger automatically internally, free-run measurement. Automatic: Starts measurement based on external start signal.   Measurement terminals  T1 terminal, T2 terminal (with built-in fuse holder), T3 terminal (110% voltage application terminal: ST5540 only) (*Step-up isolation transformer required for 110% application.)  Measurement methods  Measurement of voltage drop across body simulated resistance points Calculation and display of current values True rms measurement Measurement unit floats relative to instrument ground.  A/D conversion method $\Delta\Sigma$ method (20-bit)  Instrument-to-ground capacitance $1 M\Omega \pm 1\%$ (single-end input)  Not including voltage measurement unit, body simulated resistance (current detection circuit)  Input capacitance $150  \mathrm{pF}$ or less (between T1 and T2 terminals)		AC peak mode:500 μA/1 mA/10 mA/75 mA		
Automatic: Starts measurement based on external start signal.   Measurement terminals    T1 terminal, T2 terminal (with built-in fuse holder), T3 terminal (110% voltage application terminal: ST5540 only) (*Step-up isolation transformer required for 110% application.)   Measurement methods    Measurement of voltage drop across body simulated resistance points Calculation and display of current values   True rms measurement    Measurement unit floats relative to instrument ground.   A/D conversion method $\Delta\Sigma$ method (20-bit)    Instrument-to-ground capacitance $1 \text{ M}\Omega \pm 1\%$ (single-end input)    Not including voltage measurement unit, body simulated resistance (current detection circuit)    Input capacitance $150 \text{ pF}$ or less (between T1 and T2 terminals)	Range switching	AUTO/HOLD		
$\begin{tabular}{ll} Measurement terminals & T1 terminal, T2 terminal (with built-in fuse holder), T3 \\ terminal (110% voltage application terminal: ST5540 only) \\ (*Step-up isolation transformer required for 110% application.) \\ Measurement methods & Measurement of voltage drop across body simulated resistance points Calculation and display of current values True rms measurement Measurement unit floats relative to instrument ground. \\ A/D conversion method & $\Delta\Sigma$ method (20-bit) \\ Instrument-to-ground capacitance & 200 pF or less (between T1/T2 terminal and case ground) \\ Input resistance & 1 M$\Omega$ $\pm 1\%$ (single-end input) \\ Not including voltage measurement unit, body simulated resistance (current detection circuit) \\ Input capacitance & 150 pF or less (between T1 and T2 terminals) \\ \end{tabular}$	Trigger method	Manual: Generates trigger automatically internally, free-run measurement.		
terminal (110% voltage application terminal: ST5540 only) (*Step-up isolation transformer required for 110% application.)  Measurement methods Measurement of voltage drop across body simulated resistance points Calculation and display of current values True rms measurement Measurement unit floats relative to instrument ground.  A/D conversion method $\Delta\Sigma$ method (20-bit)  Instrument-to-ground capacitance 200 pF or less (between T1/T2 terminal and case ground)  Input resistance 1 M $\Omega$ ±1% (single-end input)  Not including voltage measurement unit, body simulated resistance (current detection circuit)  Input capacitance 150 pF or less (between T1 and T2 terminals)		Automatic: Starts measurement based on external start signal.		
	Measurement terminals	T1 terminal, T2 terminal (with built-in fuse holder), T3		
$\begin{tabular}{ll} Measurement methods & Measurement of voltage drop across body simulated resistance points \\ Calculation and display of current values \\ True rms measurement \\ Measurement unit floats relative to instrument ground. \\ A/D conversion method & $\Delta\Sigma$ method (20-bit) \\ Instrument-to-ground capacitance & 200 pF or less (between T1/T2 terminal and case ground) \\ Input resistance & 1 M\Omega \pm 1\% (single-end input) \\ Not including voltage measurement unit, body simulated resistance (current detection circuit) \\ Input capacitance & 150 pF or less (between T1 and T2 terminals) \\ \end{tabular}$		terminal (110% voltage application terminal: ST5540 only)		
		(*Step-up isolation transformer required for 110% application.)		
	Measurement methods	Measurement of voltage drop across body simulated resistance points		
$\begin{tabular}{ll} Measurement unit floats relative to instrument ground. \\ A/D conversion method & $\Delta\Sigma$ method (20-bit) \\ Instrument-to-ground capacitance & 200 pF or less (between T1/T2 terminal and case ground) \\ Input resistance & 1 M$\Omega$ $\pm 1\%$ (single-end input) \\ Not including voltage measurement unit, body simulated resistance (current detection circuit) \\ Input capacitance & 150 pF or less (between T1 and T2 terminals) \\ \end{tabular}$		Calculation and display of current values		
$ \begin{array}{llllllllllllllllllllllllllllllllllll$		True rms measurement		
		Measurement unit floats relative to instrument ground.		
	A/D conversion method	$\Delta\Sigma$ method (20-bit)		
Not including voltage measurement unit, body simulated resistance (current detection circuit)  Input capacitance  150 pF or less (between T1 and T2 terminals)	Instrument-to-ground capacitance	200 pF or less (between T1/T2 terminal and case ground)		
Input capacitance 150 pF or less (between T1 and T2 terminals)	Input resistance	1 MΩ ±1% (single-end input)		
		Not including voltage measurement unit, body simulated resistance (current detection circuit)		
(f = 100 kHz, isolated network circuit, including cables)	Input capacitance	150 pF or less (between T1 and T2 terminals)		
		(f = 100 kHz, isolated network circuit, including cables)		

CMRR (between T1 and	60 dB or greater at 60 Hz / 60 dB or greater at 10 kHz
T2 terminals and case)	40 dB or greater at 100 kHz / 40 dB or greater at 1 MHz
,	(Isolated from network circuit with fuse shorted)

#### ■ Network (body simulated resistance)

<ul> <li>Medical-use electrical devices:</li> </ul>	Basic measurement element: 1 kΩ
Network B (ST5540 only)	Filter: $10 \text{ k}\Omega + 15 \text{ nF}$
<ul> <li>Electrical Appliances and</li> </ul>	Basic measurement element: 1 kΩ
Materials Safety Act: Network A	Filter: $10 \text{ k}\Omega + 11.22 \text{ nF} + 579 \Omega$
IEC 60990: Network C	Basic measurement element: $1.5 \text{ k}\Omega + 500 \Omega$
	Filter 1: $10 \text{ k}\Omega + 22 \text{ nF}$
	Filter 2: $10 \text{ k}\Omega + (20 \text{ k}\Omega + 6.2 \text{ nF}) //9.1 \text{ nF}$
UL: Network D	Basic measurement element: 1.5 kΩ //0.15 μF
General-purpose 1: Network E	Basic measurement element: 1 kΩ
<ul> <li>General-purpose 2: Network F</li> </ul>	Basic measurement element: 2 kΩ
● IEC 61010-1: Network G	Basic measurement element: 375 $\Omega$ + 500 $\Omega$
	Filter: 375 $\Omega$ //0.22 $\mu$ F + 500 $\Omega$
Safety conductor current	Basic measurement element (35 Ω)

#### ■ Accuracy (current measurement unit)

- Temperature and humidity range within which accuracy is guaranteed: 23°C ±5°C, 80% RH or less, non-condensing

   Temperature coefficient: Add 0.1 x basic accuracy x (T-23) for operating temperature T (°C) Warm-up time: 20 min

   The range within which accuracy is guaranteed when using Network D and Network F (full-scale value for each range) is approximately 1/1.5 and 1/2, respectively.

   Calculated value when the voltage is detected across both ends of a network consisting of non-inductive resistance with a theoretical value of 1 kΩ
- The following accuracy values also apply when using voltmeter mode.

#### Measurement mode: AC\*1 / AC+DC

Pongo	Guaranteed	Resolution	Accuracy		
Range	accuracy range	Resolution	0.1 Hz≤f<15 Hz*2	DC ≤ f ≤ 100 kHz	100 kHz < f ≤ 1 MHz
50.00mA	From 4 mA	10 μA		±(2.0%rdg.+6dgt.)	±(2.0%rdg.+10dgt.)
5.000mA	From 400 µA	1 μΑ	±(4.0%rdg.+10dgt.)		
500.0μΑ	From 40 µA	0.1 μΑ			
50.00μΑ	From 4 µA	0.01 μΑ	±4.0% f.s.	±2.0% f.s.	±2.0%f.s.

## Measurement mode: AC peak\*3

Panga	Guaranteed	Resolution		Accuracy	
Range	accuracy range	Resolution	15 Hz ≤ f ≤ 10 kHz	10 kHz < f ≤ 100 kHz	100 kHz < f ≤ 1 MHz
75.0mA	From 8 mA	100 μΑ	±(2.0%rdg.+6dgt.)		±15.0%f.s.
10.00mA	From 0.8 mA	10 μΑ	±(2.0%fug.+6ugt.)	- 00/C	
1.000mA	From 100 µA	1 μΑ	±2.5% f.s.	±5.0%f.s.	
500.0 μΑ	From 40 µA	0.1 μΑ	±2.5% f.s.		±20.0%f.s.

#### Measurement: mode DC

Range	Guaranteed accuracy range	Resolution	Accuracy
50.00mA	From 4 mA	10 μΑ	
5.000mA	From 400 µA	1 μΑ	±(2.0%rdg.+6dgt.)
500.0 μΑ	From 40 µA	0.1 μΑ	
50.00 μΑ	From 4 µA	0.01 μΑ	±2.0%f.s.

#### Voltage monitor accuracy

Range	Guaranteed accuracy range	Resolution	Accuracy
300.0 V	85 V*4 to 275V	0.1 V	±(5.0%rdg.+10dgt.)

#### Current monitor accuracy (Measurement methods: Average value) response, rms calculation)

Range	Guaranteed accuracy range	Resolution	Accuracy
300.0 V	From 85 V*5	0.1 V	±(2.0%rdg.+5dgt.)

#### ■ Safety conductor current accuracy

#### Measurement mode: DC / AC\*4 / AC+DC

Range	Guaranteed accuracy Resolution		Accı	ıracy
Kange	range	Resolution	DC, 15 Hz ≤ f ≤ 100 kHz	100 kHz < f ≤ 1 MHz
50.00 mA	12.00 mA to 50.00 mA	10 μA	±(2.0%rdg.+6dgt.)	±(5.0%rdg.+20dgt.)
10.00mA	1.30 mA to 13.00 mA	10 μA	±(2.0%rdg.+6dgt.)	±(5.0%rdg.+20dgt.)

 $<sup>^{\</sup>star}1$  When using AC measurement mode, the high-pass filter frequency characteristics (fc = 4 Hz)

#### Measurement mode: AC peak

Range	Guaranteed accuracy	Resolution	Accuracy		
	range		15 Hz ≤ f ≤ 10 kHz	1 kHz < f ≤ 100 kHz	100 kHz < f ≤ 1 MHz
75.0 mA	12.0 mA to 75.00 mA	100 μA	±(2.0%rdg.+6dgt.)	±5.0%f.s.	±25.0%f.s.
10.00 mA	1.30 mA to 13.00 mA	10 μΑ	±2.5% f.s.	±5.0%f.s.	±25.0%f.s.

<sup>\*3</sup> Setting not available with Network A, B, or C (when filter off).


are added. \*2 ST5540 only.

<sup>\*4</sup> Voltages of less than 80 V are displayed as "Less than 80 V."
\*5 Currents of less than 0.5 A are displayed as "Less than 0.5 A."

# Safety Standard for Hospital Electrical Equipment

# 3157

# For JIS T 1022:2006 Measurement at Hospitals Electrical devices



#### Measuring between the grounding center and grounding terminal

Verify that the electrical resistance between the medical outlet's grounding electrode connector or medical ground terminal and medical ground center is less than or equal to 0.1  $\Omega$  by applying a current of approximately 25 A with an AC current with a no-load voltage of 6 V or less and measuring the resistance using the voltage droop method.

\* This measurement requires an extension cable (available separately). The extension cable is a special-order item; please contact your HIOKI distributor for more information.

## Combination of Instruments for Leak Current Testing and Safety Conductor Testing

The following are key parts of any safety inspection of electrical equipment:

- Leak current test: Measure with the ST5540 and ST5541.
- Safety conductor test (also known as a ground line resistance test or ground conductor test): Measure with the 3157.

The 3157 can also be used for conducting measurements under the JIS T 1022:2006 safety standard for hospital electrical equipment.

#### AC GROUNDING HITESTER 3157

Protective Ground Tester Indispensable for Standards Certification



- Standard compliance (examples) ● IEC 60065 • JIS-C1010-1
- IEC 60335-1
- IEC 60601-1
- IEC 60950-1 ● IEC 61010-1
- Electrical Appliances and Materials Safety Act
- UL (various applicable standards)

- Easily perform protective continuity testing in compliance with international safety standards and laws
  - -1) Protective continuity resistance measurement for medical devices and general electrical devices
  - -2) Ground connectivity testing when installing electrical machine tools and distribution panels
  - -3) Testing of protective grounding and isopotential grounding work for medical
- -4) Evaluation of contact status using large currents
- Feedback control system that is capable of applying a stable current even with a fluctuating load
- Soft-start function that checks the connection to the device under test before applying the current

#### Model: AC GROUNDING HITESTER 3157

Model No. (Order Code) (Note)

(100-120 / 200-240 VAC switching)

Note: This instrument is not capable of performing measurement by itself. Please purchase two Current probe 9296 units or one Current probe 9296 and one Current apply probe 9297, depending on your measurement application .:





REMOTE CONTROL BOX (DUAL) 9614 For Start/Stop control 1.5m (4.92 ft) cord length



CURRENT PROBE 9296 Alligator clip, 1.45m (4.76 ft) length 1.48m (4.86 ft) length



GP-IB INTERFACE GP-IB CONNECTOR 9518-02 For the 3157-01, built in type CABLE 9151-02 2 m (6.56 ft) length











#### Model: LEAK CURRENT HITESTER ST5541

Model No. (Order Code) (Note)

ST5541 (For el

(For electrical devices)

#### Model: LEAK CURRENT HITESTER ST5540

#### ST5540, ST5541 shared options

Model No. (Order Code) (Note)
ST5540 (For m



(For medical-use and electrical devices)



#### Leak current tester supplies

Standards require use of an isolation transformer when measuring medical-use electrical devices. Please purchase a transformer with the necessary rated capacity.

#### ■ Isolation transformer

\*Some standards require use of an isolation transformer.

Product inquiries should be directed to:

Isolation transformer model numbers

100 to 110 V (Japan): HSW-2KSP 240 to 264 V (overseas): HSW-5KSP

For more information: Tokyo Rikosha Co., Ltd. Phone: +81-48-856-3851 (reception)

http://www.tokyorikosha.co.jp

DISTRIBUTED BY

Note: Company names and product names appearing in this catalog are trademarks or registered trademarks of various companies.



**HEADQUARTERS** 81 Koizumi. Ueda, Nagano 386-1192 Japan https://www.hioki.com/

